

Product Specification

CONSTRUCTION & CHARACTERISTICS



- The YW-400XA fiber optic microscope utilizes a white light LED for coaxial illumination .Light is introduced into the optical path (axis) so that it comes out the tip of the objective lens and strikes the ferrule perpendicular to the end face .This method of illumination produces a high level of resolution providing excellent detail of scratches and contamination.
- Light source: 3*AAA batteries
- Controls: momentary on/off switch for light source and fine force control wheel
- Adapter interface: interchangeable for 2.5mm (SC, ST ,FC) and 1.25mm(LC,MU) ferrule connector

Optional Adapters

- 2.5mm APC Universal Adapter(Used for SC/APC,FC/APC,ST/APC)
- 1.25mm LC/APC connector adapter